

Getting started: **Franklin T9**

Buttons and icons

There is much you can do with your new device, so here is a quick glance of some basic items to get you started.

Buttons



Power/Menu Button Operation – Turn on the T9 and Shows menu information

	Operations	Actions
	Turn On	Press and hold the button for 3 seconds
	Turn Off	Press and hold the button until “Goodbye” message appears
	Display Wake Up	When the display is off (sleep mode) the first quick press of the button wakes up the device.
	Info Display	When the display is on, press the button quickly to go through the device menu and information.

Device Display



Wi-Fi Name (SSID) and Password:

You can find your Wi-Fi Name and Password any time you need. Just press the power/menu button shortly when the display is on.

↓

Wi-Fi Name:
Franklin T9 XXXX


↓

Password:
XXXXXXXX

Press Quickly To Wi-Fi Name Display

Press Quickly To Password Display

1. Power on your hotspot



2. Open the Wi-Fi application or controls on your laptop or Wi-Fi capable device that you want to connect to your T9. Then find your T9’s Wi-Fi name.
3. Click **Connect** and enter the Password when prompted
4. Open your browser and you are good to go!